



Purewater Storage Ltd. Trickley Coppice Farm. Coppice Lane. Middleton. Tamworth. Staffs. B78 2BU
Telephone: 0121 323 4000 Fax: 0121 323 4400 Web: www.purewaterstorage.co.uk

General conditions of Installation – One – piece, Two - piece and Semi-sectional tanks.

It is the responsibility of the client to ensure that any tank and/or associated equipment is suitable for the application and will pass through any access restriction present on site.

Unless specifically stated otherwise, it is the responsibility of the client to assemble 2 piece and semi-sectional tanks. Any quotation relating to the supply of tanks does not include on site positioning or assembly.

All Purewater storage tanks must be positioned on a flat, level and continuous foundation. The foundation should be no smaller than the external footprint of the tank and be no more than + or – 2mm over any given metre. The foundation must not have any local debris or other items to the surface or damage to the tank base will occur.

Tanks must be handled and positioned with great care. Tank bases are singled skinned and will be damaged by rough handling.

The foundation must be suitable for the purposes of providing structural support for the tank when full to maximum nominal capacity.

The lid is a structural part of the tank. For tanks fitted with a man-way; the lid should always remain in place and be fitted down correctly when the tank contains water.

Purewater tanks are not designed to support the weight of pipework or equipment other than that supplied and factory fitted to the tank.

Purewater tanks are not designed to support the weight of persons either working on or walking over the tank. The lid of any tank is NOT suitable to be used as a working platform or support of any kind. Any fall from any tank may result in death or serious injury.

Failure to adhere to these conditions of installation may result in structural failure of the tank, which may cause serious injury or death, and/or serious damage to property, equipment and other buildings structures and contents.

No liability will be accepted by Purewater Storage Ltd for any consequence resulting from incorrect installation of, or incorrect working practices associated with, any tank and/or associated equipment provided by Purewater Storage Ltd.

To avoid difficulties resulting from incorrect installation or unsuitable application of any equipment provided by Purewater Storage Ltd it is essential that our office is contacted on 0121 323 4000 prior to filling, commissioning or use of such equipment.

Connections

It is essential to note that when pad areas have been requested in specific positions to suit specific requirements, under no circumstances will the cancellation of the order be accepted once manufacture of the tank has been started.

Where connections are either factory fitted or fitted on site by Purewater Storage Ltd a water tight seal is provided.

If leaks are reported from any connection, Purewater Storage Ltd will if required, return to site to inspect the connection.

Upon inspection where any connection has been either:

- Over tightening of the compression joint to pipe-work, resulting in movement of the fitting, disturbing the seal to the tank.
- Subjected to heat from localized brazing, soldering or similar, resulting in damage to the seal to the tank.
- Damaged or effected in any way which is detrimental to the operation of the connection and/or tank.

a charge will be made for the return visit and any replacement connections & associated equipment will be charged for.

Transportation and positioning

Where provided, transportation of goods to site does not include offloading from the vehicle or positioning on site. Offloading and positioning is the responsibility of the client.

Our public & product liability insurance cover is to a maximum of £2,000,000. Insurance cover in excess of this amount can be arranged if required, and will be charged for.