



DRAWING NO. <b>MW520SQ-RF</b>		NOTES All Purewater tanks must be fully supported on a flat, level & continuous foundation providing structural support to the tank when full to maximum operating capacity. Under no circumstances should the tank body be used to provide support to pipework and ancillary items. The tank lid is a structural part of the tank and must be in place and sealed correctly when water is contained within the tank.	
ALL DIMENSIONS ± 1mm UNLESS OTHERWISE STATED	DRAWN BY <b>N.Duddy</b>	CUSTOMER <b>CUSTOMER</b>	DATE <b>04/02/11</b>
SCALE <b>1:4</b>	A4	TITLE <b>520mm Square Manway for Retro-fit usage</b>	
ALL DIMENSIONS IN MM - DO NOT SCALE			
DATE	MOD	NOTES	TANK SPECIFICATION:
	A	FIRST ISSUE	INTERNAL DIMS
			EXTERNAL DIMS
			NOM. CAPACITY
			DRY WEIGHT
			INSULATION
			25mm
<p><b>purewater storage ltd</b></p> <p>Trusley Copples Farm Copples Farm Medkirk Tarnworth Sails B78 2BU</p>		<p>Tel: 0121 323 4000 Fax: 0121 323 4400 www.purewaterstorage.co.uk</p>	